



# SYSTEM OF NARCOTICS IDENTIFICATION

## INSTRUCTIONS FOR USE

### TEST I - LEIBERMAN'S REAGENT

#### FOR: General Screening Test

##### Test Function

1. This reagent system presumptively identifies several drugs when used in conjunction with the other field drug kits included in the NIK® Club Drug Kit. This test is to be used after a Brown result in Test A or a clear result in Test A followed by a no change result in Test G. Please refer to the NIK® Identidrug™ Chart for results.

##### How to Use Test I

1. Remove clip and insert into the test pack an amount of powdered suspect material that would fit inside this circle.  Reseal with clip and tap gently to assure material falls to the bottom of the pouch.
2. With the printed side of the test pouch facing you, break ampule by squeezing the center of the ampoule with the tips of the thumb and forefinger. Agitate gently and observe the color or color changes.

##### Interpretation of Resulting Colors

1. Refer to the NIK® Identidrug™ Chart for test results.
2. It is advisable that this test be used in conjunction with the other tests listed on the NIK® Identidrug™ Chart.
3. If the resulting color(s) is not listed on the NIK® Identidrug™ Chart, stop testing. The NIK® Polytesting System has not presumptively identified any controlled substances.

#### CAUTION

- A. Since these tests contain strong acids, it is suggested that Test F - Acid Neutralizer be used after testing and before disposal.
- B. Before discarding used test packs, remove clip and add one measure of acid neutralizer from Test F.
- C. Add slowly to prevent bubbling over.
- D. DO NOT reseal the test pouch until effervescence has completely stopped.
- E. Reseal pouch with clip and discard in a tamper-free disposal unit.
- F. No attempt should be made to crush the glass particles after the ampoules are broken.
- G. **Antidote:** In case of contact, immediately flush eyes or skin with water for at least 15 minutes while removing contaminated clothing and shoes. If swallowed, do not give emetics. Contact a physician.

#### WARNING

These tests are NOT designed for use with liquid samples.



13386 International Parkway  
Jacksonville, Florida 32218  
904.485.1836 FAX: 904.741.5407  
© 2105 Safariland, LLC

A Brand of the Safariland Group